



ED-HMI2020-070C

Application Guide

EDA Technology Co., LTD

May 2024

Contact Us

Thank you very much for purchasing and using our products, and we will serve you wholeheartedly.

As one of the global design partners of Raspberry Pi, we are committed to providing hardware solutions for IOT, industrial control, automation, green energy and artificial intelligence based on Raspberry Pi technology platform.

You can contact us in the following ways:

EDA Technology Co.,LTD

Address: Building 29, No.1661 Jialuo Highway, Jiading District, Shanghai

Mail: sales@edatec.cn

Phone: +86-18217351262

Website: <https://www.edatec.cn>

Technical Support:

Mail: support@edatec.cn

Phone: +86-18627838895

Wechat: zzw_1998-

Copyright Statement

ED-HMI2020-070C and its related intellectual property rights are owned by EDA Technology Co.,LTD.

EDA Technology Co.,LTD owns the copyright of this document and reserves all rights. Without the written permission of EDA Technology Co.,LTD, no part of this document may be modified, distributed or copied in any way or form.

Disclaimer

EDA Technology Co.,LTD does not guarantee that the information in this manual is up to date, correct, complete or of high quality. EDA Technology Co.,LTD also does not guarantee the further use of this information. If the material or non-material related losses are caused by using or not using the information in this manual, or by using incorrect or incomplete information, as long as it is not proved that it is the intention or negligence of EDA Technology Co.,LTD, the liability claim for EDA Technology Co.,LTD can be exempted. EDA Technology Co.,LTD expressly reserves the right to modify or supplement the contents or part of this manual without special notice.

Foreword

Related Manuals

All kinds of product documents contained in the product are shown in the following table, and users can choose to view the corresponding documents according to their needs.

Documents	Instruction
ED-HMI2020-070C Datasheet	This document introduces the product features, software and hardware specifications, dimensions and ordering codes of ED-HMI2020-070C series to help users understand the overall system parameters of the products.
ED-HMI2020-070C User Manual	This document introduces the appearance, installation, startup and configuration of ED-HMI2020-070C series to help users use the product better.
ED-HMI2020-070C Application Guide	This document introduces the OS downloading, flashing to eMMC and partial configuration of ED-HMI2020-070C series to help users use the product better.

Users can visit the following website for more information:

<https://www.edatec.cn>




Reader Scope

This manual is applicable to the following readers:

- ◆ Mechanical Engineer
- ◆ Electrical Engineer
- ◆ Software Engineer
- ◆ System Engineer

Related Agreement

Symbolic Convention

Symbolic	Instruction
	Prompt symbols, indicating important features or operations.
	Notice symbols, which may cause personal injury, system damage, or signal interruption/loss.
	May cause great harm to people.

Safety Instructions

- ◆ This product should be used in an environment that meets the requirements of design specifications, otherwise it may cause failure, and functional abnormality or component damage caused by non-compliance with relevant regulations are not within the product quality assurance scope.
- ◆ Our company will not bear any legal responsibility for personal safety accidents and property losses caused by illegal operation of products.
- ◆ Please do not modify the equipment without permission, which may cause equipment failure.
- ◆ When installing equipment, it is necessary to fix the equipment to prevent it from falling.
- ◆ If the equipment is equipped with an antenna, please keep a distance of at least 20cm from the equipment during use.
- ◆ Do not use liquid cleaning equipment and keep away from liquids and flammable materials.
- ◆ This product is only supported for indoor use.

Content

Foreword	i
Related Manuals	i
Reader Scope	i
Related Agreement	ii
Symbolic Convention	ii
Safety Instructions.....	iii
1 Installing OS.....	1-1
1.1 Downloading OS File.....	1-2
1.2 Flashing to eMMC (optional).....	1-3
1.3 Flashing to SD Card (optional).....	错误!未定义书签。
2 Firmware Update.....	2-1

1 Installing OS

This chapter introduces how to download OS file and flash to eMMC.

- ✓ Downloading OS File
- ✓ Flashing to eMMC

1.1 Downloading OS File

If the operating system is damaged during use, you need to re-download the latest version of OS file and flash to eMMC. The download path is: [ED-HMI2020-070C/raspios](#).

1.2 Flashing to eMMC

ED-HMI2020-070C supports booting the OS from eMMC by default. If you need use a new OS, you need flash to eMMC. It is recommended to use the Raspberry Pi official tools. The download paths are as follows:

- ◆ Raspberry Pi Imager: https://downloads.raspberrypi.org/imager/imager_latest.exe
- ◆ SD Card Formatter: <https://www.sdcardformatter.com/download/>
- ◆ Rpiboot: https://github.com/raspberrypi/usbboot/raw/master/win32/rpiboot_setup.exe

Preparation:

- ◆ The downloading and installation of the official tools to the computer have been completed.
- ◆ A Micro USB to USB-A cable has been prepared.
- ◆ The OS file has been obtained.


Steps:

The steps are described using Windows system as an example.

1. Connect the power cord and USB flashing cable, as shown in the figure below.
 - Connecting to power cord: One end is connected to DC Jack connector on the device side, and the other end is connected to the external power supply.




- Connecting to USB cable: One end is connected to the Micro USB port on the device side, and the other end is connected to the USB port on the PC.




2. Press and hold the PROGRAMMING button when it is not powered on, then power on the device (release the PROGRAMMING button after powering on), and the device will enter the programming mode.
3. Open **rpiboot tool** to automatically convert the drive to a letter.

```
rpiboot
RPiBOOT: build-date Dec 16 2022 version 20221215-105525 1afa26c5
Waiting for BCM2835/6/7/2711...
Loading embedded: bootcode4.bin
Sending bootcode.bin
Successful read 4 bytes
Waiting for BCM2835/6/7/2711...
```


4. After the completion of the drive letter, the drive letter will pop up in the lower right corner of the computer, as shown in the figure below E drive.




5. Open **SD Card Formatter**, select the formatted drive letter, and click "Format" at the lower right to format.




6. In the pop-up prompt box, select "Yes".
7. When the formatting is completed, click "OK" in the prompt box.
8. Close **SD Card Formatter**.
9. Open **Raspberry Pi Imager**, select "CHOOSE OS" and select "Use Custom " in the pop-up pane.




10. According to the prompt, select the OS file under the user-defined path and return to the main page.
11. Click "CHOOSE STORAGE", select the default device in the "Storage" interface, and return to the main page.




12. Click "NEXT", select "NO " in the pop-up "Use OS customization?" pane.



13. Select "YES" in the pop-up "Warning" pane to start writing the image.



14. After the OS writing is completed, the file will be verified.



15. After the verification is completed, click "CONTINUE" in the pop-up "Write Successful" box.
16. Close **Raspberry Pi Imager**, remove USB cable and power on the device again.

2 Firmware Update

After the system starting normally, you can execute the following commands in the command pane to upgrade the firmware and optimize the software functions.

sudo apt update

sudo apt upgrade